

# **Antifouling SeaGuardian**

# **Product description**

This is a one component antifouling coating based on ion exchange technology. It provides an efficient fouling protection. This is achieved by self polishing characteristics reducing hull deterioration. To be used as finish coat in immersed environments only. Suitable on approved primers and tie coats on aluminium and carbon steel substrates. It can be applied at sub zero surface temperatures.

## Scope

The Application Guide offers product details and recommended practices for the use of the product.

The data and information provided are not definite requirements. They are guidelines to assist with efficient and safe use, and optimum service of the product. Adherence to the guidelines does not relieve the applicator of responsibility for ensuring that the work meets specification requirements. Jotuns liability is in accordance with general product liability rules.

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

## **Referred standards**

Reference is generally made to ISO Standards. When using standards from other regions it is recommended to reference only one corresponding standard for the substrate being treated.

# **Surface preparation**

The required quality of surface preparation can vary depending on the area of use, expected durability and if applicable, project specification.

## **Process sequence**

Surface preparation and coating application should normally be done only after all welding, degreasing, removal of sharp edges, weld spatter and treatment of welds is complete. It is important that all hot work is done before coating application.

## **Coated surfaces**

#### Organic primers/intermediates

The existing hull coating system must be high pressure washed at 350 bar. Evaluate according to ASTM D610 pictorial assessment guide of these defects combined: mechanical damage, rust/bare metal, flaking, cracks, checks, blisters, animal fouling remains/roots.

Jotun's general recommendation for maximum salt contamination for under water areas is 80 mg/m² NaCl.

New tie coat or new antifouling

Date of issue: 8 May 2020 Page: 1/7



This product can be applied on top of most of Jotun's other antifouling products assuming the surface is clean and dry.

When applying to new tie coat or new antifouling, remove any contamination that could interfere with coating adhesion by methods such as degreasing with alkali detergent and/or high pressure freshwater washing. If the tie coat's maximum over coating interval has been exceeded, another coat of tie coat is required, or the surface of the hardened tie coat should be thoroughly abraded for roughness by powered orbital/eccentric/dual action abrasive discs on soft backing pads, or by sweep blasting using a fine grade of blast media. Coarse blast media may damage the remaining coatings and will roughen the surface excessively. This may compromise the hull's smoothness, hydrodynamic properties and consequent through-water performance.

#### Aged antifouling with leached layer

The spent, skeletal, porous layer at the surface of aged antifouling known as leached layer can cause popping/pinholes/bubbling when over coated. Furthermore the leached layer will be weaker in cohesive strength than a new antifouling system. Therefore, all efforts should be made to properly remove the leached layer. Various factors will determine the leached layer's thickness and its strength and integrity; mainly the antifouling's binder technology, but also the vessel's speed and the water temperature where the ship was trading (slow speeds and cold waters often result in thicker leached layer). Leached layers should be removed by very thorough high pressure freshwater washing.

Note that the use of a tie coat is no substitute for proper washing of aged antifouling. Sealer coatings are not significantly better at sealing porous surfaces than are antifoulings. Popping or compromised adhesion may still result. Furthermore, sealing aged antifouling has the disadvantage of blocking off antifouling that might become exposed, and therefore provide fouling protection later in service.

Practically Jotun recommends doing a test spray with thinned antifouling on the washed and dry surface in order to check for potential popping. Please note that the popping itself will have no negative effect on the performance of the antifouling properties, however it will have a negative visual effect.

#### Aged antifouling: Cracked, flaked or "sandwiched" coating systems

It should again be highlighted that if the coating exhibits weak adhesion or has been spot repaired for more than 3 dockings or 15 years, the general recommendation is to blast the surface to Sa 2 as per ISO 8501-1.

Aged antifouling systems of suspect physical integrity which exhibit cracking, flaking and/or heavy 'sandwiching' of multiple layers are best fully removed by grit blasting to Sa 2 or by water-jetting back to WJ 2. An alternative solution to remove existing antifouling paints by sweeping the surface by the means of hydrojetting or abrasive blast cleaning using fine grit. The sweeping should be done down to intact primer system, the method should be with focus on not to create unnecessary surface roughness.

Cracking in an antifouling should not be confused with surface "checking" which would appear as superficial cracks in top of the surface, but not penetrating the full coating layer. A checked surface should be carefully washed in order to remove salts or other contamination but would then be possible to over coat.

This type of antifouling will leave a hard thick leached layer, which will be suitable for over coating, but after repeating the over coating for 3-4 applications, the coating will appear to be cracking or giving a "mosaic" view on the surface. This is simply due to old leached layer creating tension in the film, causing surface cracking. When the mosaic phenomenon is appearing, one should consider to reblast the surface as described above.

Cracking is defined as deep cracks penetrating the entire coating layer. In case of cracking the adhesion of the surface should be carefully checked. This should be done using x-cut method as per ISO 16276-2, where level 5 would be unacceptable. In case of level 4 or lower, it is recommended to carry out careful high pressure fresh water hosing in order to remove leach layer and loose paint. Note: If abrasive blasting is to be carried out on mechanical damages in the vicinity of a cracked surface, it is recommended to carry out the blasting in large square boxes with feathering of the overlapping zones, avoiding further damage of a relatively weak coating system.

### Exposed sealer/tie coat

In case of through polishing exposing the existing tie coat another new coat of tiecoat is required in order to ensure proper adhesion to the aged sealer/tiecoat. Before any application takes place it should be high pressure fresh water cleaned as per above guidelines. Overlapping with new sealer coat on top of existing, intact antifouling should be limited as much as practically possible.

Date of issue: 8 May 2020 Page: 2/7



# **Application**

## Acceptable environmental conditions - before and during application

Before application, test the atmospheric conditions in the vicinity of the substrate for the dew formation according to ISO 8502-4.

Air temperature 5-60 °C Substrate temperature 5-50 °C Relative Humidity (RH) 10-85 %

The following restrictions must be observed:

- Only apply the coating when the substrate temperature is at least 3 °C (5 °F) above the dew point
- Do not apply the coating if the substrate is wet or likely to become wet
- Do not apply the coating if the weather is clearly deteriorating or unfavourable for application or curing
- Do not apply the coating in high wind conditions

## **Product mixing**

#### **Product mixing**

Single pack

### **Thinner/Cleaning solvent**

Thinner: Jotun Thinner No. 7

### **Application data**

### **Spray application**

#### **Airless Spray Equipment**

Pump ratio (minimum): 42:1

Pressure at nozzle (minimum) : 150 bar/2100 psi

Nozzle tip (inch/1000): 21-31 Nozzle output (litres/minute): 1.3-4.2 Filters (mesh): 50-70

Several factors influence, and need to be observed to maintain the recommended pressure at the nozzle. Among factors causing pressure drop are:

- extended hoses or hose bundles
- extended hose whip-end line
- small internal diameter hoses
- high paint viscosity
- large spray nozzle size
- inadequate air capacity from compressor
- incorrect or clogged filters

Date of issue: 8 May 2020 Page: 3/7



# Film thickness per coat

#### Typical recommended specification range

## Film thickness measurement

#### Wet film thickness (WFT) measurement and calculation

To ensure correct film thickness, it is recommended to measure the wet film thickness continuously during application using a painter's wet film comb (ISO 2808 Method 1A).

#### Dry film thickness (DFT) measurement

When the coating has cured to hard dry state the dry film thickness can be checked to SSPC PA 2 or equivalent standard using statistical sampling to verify the actual dry film thickness. Measurement and control of the WFT and DFT on welds is done by measuring adjacent to and no further than 15 mm from the weld.

#### **Ventilation**

Sufficient ventilation is very important to ensure proper drying/curing of the film.

#### **Coating loss**

The consumption of paint should be controlled carefully, with thorough planning and a practical approach to reducing loss. Application of liquid coatings will result in some material loss. Understanding the ways that coating can be lost during the application process, and making appropriate changes, can help reducing material loss.

Some of the factors that can influence the loss of coating material are:

- type of spray gun/unit used
- air pressure used for airless pump or for atomization
- orifice size of the spray tip or nozzle
- fan width of the spray tip or nozzle
- the amount of thinner added
- the distance between spray gun and substrate
- the profile or surface roughness of the substrate. Higher profiles will lead to a higher "dead volume"
- the shape of the substrate target
- environmental conditions such as wind and air temperature

# **Drying and Curing time**

Substrate temperature	5 °C	10 °C	23 °C	40 °C
Surface (touch) dry	1 h	1 h	30 min	30 min
Dry to over coat, minimum	12 h	10 h	8 h	6 h
Dried/cured for immersion	12 h	10 h	8 h	6 h

Drying and curing times are determined under controlled temperatures and relative humidity below 85 %, and at average of the DFT range for the product.

Date of issue: 8 May 2020 Page: 4/7



Surface (touch) dry: The state of drying when slight pressure with a finger does not leave an imprint or reveal tackiness.

Dry to over coat, minimum: The recommended shortest time before the next coat can be applied.

Dried/cured for immersion: Minimum time before the coating can be permanently immersed in sea water.

## Maximum over coating intervals

Maximum time before thorough surface preparation is required. The surface must be clean and dry and suitable for over coating. Inspect the surface for chalking and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area by low-pressure water cleaning using fresh water.

If maximum over coating interval is exceeded the surface should in addition be carefully roughened to ensure good inter coat adhesion.

## Areas for immersed exposure

Average temperature during drying/curing	5 °C 10 °C 23 °C 40 °C		
Itself	extended extended extended		

### Other conditions that can affect drying / curing / over coating

#### Repair of coating system

#### Damages to the coating layers:

Prepare the area through sandpapering or grinding, followed by thorough cleaning/vacuuming. When the surface is clean and dry the coating may be over coated by itself or by another product, ref. original specification.

Always observe the maximum over coating intervals. If the maximum over coating interval is exceeded the surface should be carefully roughened in order to ensure good intercoat adhesion.

### Damages exposing bare substrate:

Remove all rust, loose paint, grease or other contaminants by spot blasting, mechanical grinding, water and/or solvent washing. Feather edges and roughen the overlap zone of surrounding intact coating. Apply the coating system specified for repair.

#### Repair of damaged areas

Sags and runs can be caused by too high wet film thickness, too much thinner added or the spray gun used too close to the surface.

Repair by using a paint brush to smooth the film when still wet. Sand down to a rough, even surface and recoat if dry.

Orange peel can be caused by poor flow/levelling properties of the paint, poor atomization of the paint, thinner evaporating too fast or the spray gun held too close to the surface.

This can be rectified by abrading the surface and applying an additional coat after having adjusted the application properties or the application technique.

Dry spray can be caused by poor atomization of the paint, spray gun held too far from the surface, high air temperature, thinner evaporating too fast or coating applied in windy conditions.

Physically drying paints can be solvent wiped and another coat applied. If area is too large to practically solvent wipe, consider sandpapering or grinding, followed by thorough washing. When the surface is dry the coating may be over coated by itself.

Date of issue: 8 May 2020 Page: 5/7

For your nearest local Jotun office, please visit our website at www.jotun.com.



# **Quality assurance**

The following information is the minimum required. The specification may have additional requirements.

- Confirm that all welding and other metal work has been completed before commencing pre-treatment and surface preparation
- Confirm that installed ventilation is balanced and has the capacity to deliver and maintain the RAQ
- Confirm that the required surface preparation standard has been achieved and is held prior to coating application
- Confirm that the climatic conditions are within recommendations in the AG, and are held during the application
- Confirm that the required number of stripe coats have been applied
- Confirm that each coat meets the DFT requirements in the specification
- Confirm that the coating has not been adversely affected by rain or other factors during curing
- Observe that adequate coverage has been achieved on corners, crevices, edges and surfaces where the spray gun cannot be positioned so that its spray impinges on the surface at 90° angle
- Observe that the coating is free from defects, discontinuities, insects, abrasive media and other contamination
- Observe that the coating is free from misses, sags, runs, wrinkles, fat edges, mud cracking, blistering, obvious pinholes, excessive dry spray, heavy brush marks and excessive film build
- Observe that the uniformity and colour are satisfactory

All noted defects shall be fully repaired to conform to the coating specification.

#### **Caution**

This product is for professional use only. The applicators and operators shall be trained, experienced and have the capability and equipment to mix/stir and apply the coatings correctly and according to Jotun's technical documentation. Applicators and operators shall use appropriate personal protection equipment when using this product. This guideline is given based on the current knowledge of the product. Any suggested deviation to suit the site conditions shall be forwarded to the responsible Jotun representative for approval before commencing the work.

For further advice please contact your local Jotun office.

#### **Health and safety**

Please observe the precautionary notices displayed on the container. Use under well ventilated conditions. Do not inhale spray mist. Avoid skin contact. Spillage on the skin should immediately be removed with suitable cleanser, soap and water. Eyes should be well flushed with water and medical attention sought immediately.

#### **Accuracy of information**

Always refer to and use the current (last issued) version of the TDS, SDS and if available, the AG for this product. Always refer to and use the current (last issued) version of all International and Local Authority Standards referred to in the TDS, AG & SDS for this product.

## **Colour variation**

Some coatings used as the final coat may fade and chalk in time when exposed to sunlight and weathering effects. Coatings designed for high temperature service can undergo colour changes without affecting performance. Some slight colour variation can occur from batch to batch. When long term colour and gloss retention is required, please seek advice from your local Jotun office for assistance in selection of the most suitable top coat for the exposure conditions and durability requirements.

#### Reference to related documents

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

When applicable, refer to the separate application procedure for Jotun products that are approved to classification societies such as PSPC, IMO etc.

# Symbols and abbreviations

min = minutes

TDS = Technical Data Sheet

Date of issue: 8 May 2020 Page: 6/7



h = hours

d = days

°C = degree Celsius

° = unit of angle

 $\mu m = microns = micrometres$ 

g/l = grams per litre

g/kg = grams per kilogram

 $m^2/I = square metres per litre$ 

mg/m² = milligrams per square metre

psi = unit of pressure, pounds/inch²

Bar = unit of pressure

RH = Relative humidity (% RH)

UV = Ultraviolet

DFT = dry film thickness

WFT = wet film thickness

AG = Application Guide

SDS = Safety Data Sheet

VOC = Volatile Organic Compound

MCI = Jotun Multi Colour Industry (tinted colour)

RAQ = Required air quantity

PPE = Personal Protective Equipment

EU = European Union

UK = United Kingdom

EPA = Environmental Protection Agency

ISO = International Standards Organisation

ASTM = American Society of Testing and Materials

AS/NZS = Australian/New Zealand Standards NACE = National Association of Corrosion Engineers

SSPC = The Society for Protective Coatings

PSPC = Performance Standard for Protective Coatings

IMO = International Maritime Organization

ASFP = Association for Specialist Fire Protection

# **Disclaimer**

The information in this document is given to the best of Jotun's knowledge, based on laboratory testing and practical experience. Jotun's products are considered as semi-finished goods and as such, products are often used under conditions beyond Jotun's control. Jotun cannot guarantee anything but the quality of the product itself. Minor product variations may be implemented in order to comply with local requirements. Jotun reserves the right to change the given data without further notice.

Users should always consult Jotun for specific guidance on the general suitability of this product for their needs and specific application practices.

If there is any inconsistency between different language issues of this document, the English (United Kingdom) version will prevail.

Date of issue: 8 May 2020 Page: 7/7