

Baltoflake Ecolife TU

Product description

This is a styrene free glass flake reinforced unsaturated polyester coating. It is an ultra high build, extremely abrasion resistant and fast curing barrier coating. Developed specifically as an easy to apply, touch up product for small scale repair work. Can be used as a primer or finish coat in atmospheric and immersed environment. Suitable for properly prepared carbon steel and application over Baltoflake or Baltoflake Ecolife.

Scope

The Application Guide offers product details and recommended practices for the use of the product.

The data and information provided are not definite requirements. They are guidelines to assist with efficient and safe use, and optimum service of the product. Adherence to the guidelines does not relieve the applicator of responsibility for ensuring that the work meets specification requirements. Jotuns liability is in accordance with general product liability rules.

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

Referred standards

Reference is generally made to ISO Standards. When using standards from other regions it is recommended to reference only one corresponding standard for the substrate being treated.

Surface preparation

The required quality of surface preparation can vary depending on the area of use, expected durability and if applicable, project specification.

Process sequence

Surface preparation and coating should normally be commenced only after all welding, degreasing, removal of sharp edges, weld spatter and treatment of welds is complete. It is important that all hot work is completed before coating commences.

Soluble salts removal

Soluble salts have a negative impact on the coating systems performance, especially when immersed. Jotun's general recommendations for maximum soluble salts (sampled and measured as per ISO 8502-6 and -9) content on a surface are: For areas exposed to (ISO 12944-2): C1-C4: 200 mg/m² C5: 100 mg/m² Im1-Im3: 80 mg/m²

Carbon steel

Initial rust grade

The steel shall be Rust Grade A or B (ISO 8501-1). For steel with Rust Grades C or D, contact your nearest Jotun office for advice.

Initial inspection and pretreatment

Date of issue: 3 April 2023

Page: 1/7

This Application Guide supersedes those previously issued.



Inspect the surface for contaminations and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area by Low-Pressure Water Cleaning (LPWC) to Wa 1 (ISO 8501-4) using fresh water.

Non-contaminated areas shall be washed down by Low-Pressure Water Cleaning (LPWC) to Wa 1 (ISO 8501-4) using fresh water to reduce the concentration of surface chlorides.

Metal finishing

Defective welds shall be replaced and treated to an acceptable finish before painting. Temporary welds and brackets shall be ground to a flat finish after removal from the parent metal. All edges shall be ground to a minimum radius of 2.0 mm after a minimum three passes with a mechanical grinder fitted with appropriate abrasive. All sharp irregularities, burrs, slivers, slag and spatter on welds, whether apparent before or after blast cleaning, shall be removed before the commencement of coating application. Weld smoke shall be removed by washing by low-pressure Water Cleaning LP WC method to Wa 1 (ISO 8501-4) using fresh water. For areas in corrosivity category C5, Im1-3 the requirement are for the steel to conform to grade P2 (ISO 8501-3) Table 1. All edges shall have a rounded radius of minimum 2 mm subjected to three pass grinding or equally effective method. One may use a mechanical grinder fitted with a suitable abrasive disc. All sharp irregularities, burrs, slivers, slag and spatter on welds, whether apparent before or after blast cleaning, shall be removed by the a suitable abrasive disc. All sharp are equily effective method. One may use a mechanical grinder fitted with a suitable abrasive disc. All sharp irregularities, burrs, slivers, slag and spatter on welds, whether apparent before or after blast cleaning, shall be removed before coating application. It is recommended that welding smoke should be removed by low-pressure Water Cleaning LP WC method (ISO 8501-4) Wa 1 using fresh water. Welding smoke residues are water soluble and could cause blistering if not removed by washing before blasting.

Abrasive blast cleaning

Cleanliness

After pre-treatment is complete, the surface shall be dry abrasive blast cleaned to Sa $2\frac{1}{2}$ (ISO 8501-1) using abrasive media suitable to achieve a sharp and angular surface profile.

Surface profile

The surface shall have a sharp and angular surface profile 55-130 μ m, grade Medium to Coarse G (ISO 8503-2). Measure the achieved profile with surface replication tape (Testex) (ISO 8503-5) or by surface roughness stylus instrument (ISO 8503-4).

Abrasive media quality

The selected abrasive must be compatible with both the surface to be blast cleaned and the specified coating system. The abrasive shall meet specifications as per relevant parts of ISO 11124 (Specification for metallic blast-cleaning abrasives), or ISO 11126 (Specification for non-metallic blast-cleaning abrasives). It should be sampled and tested as per relevant parts of ISO 11125 (metallic abrasives) or ISO 11127 (non-metallic abrasives). Dry storage of abrasive and shelter for blasting pots is necessary to prevent equipment becoming clogged with damp abrasive.

All abrasive blast media used should be new and not recirculated, with the exception of steel grit. If this is utilized the circulation process must include a cleaning process.

Compressed air quality

The supply of clean air to blasting pots must be secured to avoid contamination of abrasive and thereby of blast cleaned surfaces. Compressors must be fitted with sufficient traps for oil and water. It is also recommended to fit two water separators at the blasting machine to ensure a supply of moisture-free air to the abrasive chamber.

Dust contamination

At the completion of abrasive blasting the prepared surface shall be cleaned to remove residues of corrosion products and abrasive media, and inspected for surface particulate contamination. Maximum contamination level is rating 2 (ISO 8502-3) as per Figure 1. Dust size no greater than class 2.

Hand and Power Tool Cleaning

Power tool cleaning

Date of issue: 3 April 2023

Page: 2/7

This Application Guide supersedes those previously issued.



Minor damage of the coating may be prepared to St 3 (ISO 8501-1) with a surface roughness of minimum 50µm using a Bristle blaster or a suitable rotating fiber disc, like 3M CSD or similar. Leading edges of intact coating around damage shall be feathered to ensure a smooth transition from the coating to the prepared steel. Consecutive layers of coating shall be feathered to expose each layer and new coating shall always overlap to an abraded existing layer. Mechanical repairs are only accepted for minor areas of damage where abrasive blasting is expected to create more damage to the coating system than actual benefit to the performance of the coating system; i.e. damage/defects found after immersion testing.

Overlapping zones to intact coating shall have all leading edges feathered back by sanding methods to remove all sharp leading edges and establish a smooth transition from the exposed substrate to the surrounding coating. Consecutive layers of coating shall be feathered to expose each layer and new coating shall always overlap to an abraded existing layer. Abrade intact coatings around the damaged areas for a minimum 100 mm to ensure a mat, rough surface profile, suitable for over coating.

Water jetting

Due to risk of flashrust which is not recommend for these types of coating, water jetting of steel substrates is not recommended.

Application

Acceptable environmental conditions - before and during application

Before application, test the atmospheric conditions in the vicinity of the substrate for the dew formation according to ISO 8502-4.

Air temperature	5 - 40	°C
Substrate temperature	5 - 50	°C
Relative Humidity (RH)	10 - 85	%

The following restrictions must be observed:

- Only apply the coating when the substrate temperature is at least 3 °C (5 °F) above the dew point
- Do not apply the coating if the substrate is wet or likely to become wet
- Do not apply the coating if the weather is clearly deteriorating or unfavourable for application or curing
- Do not apply the coating in high wind conditions

Product mixing

Product mixing

Mixing ratio is fixed as 2.25vol% due to fixed package size. Mix the two components thoroughly by trowel/ spatula until an even colour and appearance. Mix for minimum 1 minute.

Induction time and Pot life

Paint temperature	23 °C
Pot life	15-20 min

Higher temperature will reduce the pot life.

Date of issue: 3 April 2023

Page: 3/7

This Application Guide supersedes those previously issued.

Application Guide Baltoflake Ecolife TU



Be aware that the curing of Baltoflake Ecolife TU when mixed with the peroxide, develops heat in an exothermic reaction. If significant volume of mixed paint is left in the can the temperature will increase at the end of the potlife, which can be reduced by filling water into the can after gelling.

Thinner/Cleaning solvent

Cleaning solvent:

Jotun Thinner No. 17 / Jotun Thinner No. 27

Film thickness per coat

Typical recommended specification range

Dry film thickness	600	-	1500	μm
Wet film thickness	650	-	1610	μm
Theoretical spreading rate	1.6	-	0.6	m²/l

All vinyl ester and polyester resin systems are subject to some shrinkage during the curing process. This results in a practical spreading rate lower than the theoretically calculated. The shrinkage depends on actual dry film thickness applied and conditions during application.

Can be applied up to 100 % higher than maximum specified film thickness without loss of technical properties.

For the application Jotun recommend that the product is applied using a trowel or application blade, pull the product as few times as possible to achieve the required film thickness.

In order to minimize shrinkage stress within the dry film and to prevent possible air entrapment, a typical DFT of 600µm is recommended per layer. However a maximum of 1500µm DFT per layer can be applied without affecting product performance.

Higher film thickness could result in shrinkage stress within the dry film

Film thickness measurement

Wet film thickness (WFT) measurement and calculation

To ensure correct film thickness, it is recommended to measure the wet film thickness continuously during application using a painter's wet film comb (ISO 2808 Method 1A). The measurements should be done as soon as possible after application.

Fast drying paints may give incorrect (too low) readings resulting in excessive dry film thickness. For multi layer physically drying (resoluble) coating systems the wet film thickness comb may give too high readings resulting in too low dry film thickness of the intermediate and top coats.

Use a wet-to-dry film calculation table (available on the Jotun Web site) to calculate the required wet film thickness per coat.

Dry film thickness (DFT) measurement

When the coating has cured to hard dry state the dry film thickness can be checked to SSPC PA 2 or equivalent standard using statistical sampling to verify the actual dry film thickness. Measurement and control of the WFT and DFT on welds is done by measuring adjacent to and no further than 15 mm from the weld.

Ventilation

Sufficient ventilation is very important to ensure proper drying/curing of the film.

Coating loss

Date of issue: 3 April 2023

Page: 4/7

This Application Guide supersedes those previously issued.



The consumption of paint should be controlled carefully, with thorough planning and a practical approach to reducing loss. Application of liquid coatings will result in some material loss. Understanding the ways that coating can be lost during the application process, and making appropriate changes, can help reducing material loss.

Some of the factors that can influence the loss of coating material are:

- the profile or surface roughness of the substrate. Higher profiles will lead to a higher "dead volume"
- the shape of the substrate target

- environmental conditions such as wind and air temperature

Drying and Curing time

Substrate temperature	5 °C	10 °C	15 °C	23 °C	40 °C
Surface (touch) dry	4 h	3 h	2.5 h	2 h	45 min
Walk-on-dry	4 h	3 h	2.5 h	2 h	45 min
Dry to over coat, minimum	4 h	3 h	2.5 h	2 h	45 min
Dried/cured for service	3 d	2 d	2 d	12 h	4 h

If applied in two coats, it is recommended to apply the second coat as soon as possible after Dry to overcoat, and within the maximum overcoating time of 16 hrs. If overcoating time is exceeded, sanding is recommended to ensure optimum adhesion between the coats.

Drying and curing times are determined under controlled temperatures and relative humidity below 85 %, and at average of the DFT range for the product.

Surface (touch) dry: The state of drying when slight pressure with a finger does not leave an imprint or reveal tackiness.

Walk-on-dry: Minimum time before the coating can tolerate normal foot traffic without permanent marks, imprints or other physical damage.

Dry to over coat, minimum: The recommended shortest time before the next coat can be applied.

Dried/cured for service: Minimum time before the coating can be permanently exposed to the intended environment/medium.

Other conditions that can affect drying / curing / over coating

Repair of coating system

Damages to the coating layers:

Prepare the area through sandpapering or grinding, followed by thorough cleaning/vacuuming. When the surface is clean and dry the coating may be over coated by itself or by another product, ref. original specification.

Always observe the maximum over coating intervals. If the maximum over coating interval is exceeded the surface should be carefully roughened in order to ensure good intercoat adhesion.

Damaged areas exposing bare steel:

Remove all rust, loose paint, grease or other contaminants by spot abrasive blasting, mechanical grinding, water and/or thinner washing. Feather edges of surrounding intact coating.

Too thin areas: Remove contaminants and roughen surface and reapply as soon as possible after surface is cleaned to prevent contaminants on the surface.

Overlapping zones to intact coating shall be masked off with a minimum 200 mm distance to the damage and should cover the surrounding area so that overspray to sound coating does not occur during repair application. Edges of intact coating around damage shall be feathered to ensure a smooth transition from the coating to the prepared steel. Consecutive layers of coating shall be feathered to expose each layer and new coating shall

Date of issue: 3 April 2023

Page: 5/7

This Application Guide supersedes those previously issued.



always overlap to an abraded existing layer.

Repair of damaged areas

Sags and runs can be caused by too high wet film thickness, too much thinner added or the spray gun used too close to the surface.

Smoothen the wet film with a paint brush to repair small sags and runs. More extensive sags and runs must be removed using scrapers or rags depending on severity and accessability.

Sand down to a rough, even surface and re-coat if cured.

Coating film continuity

Jotun recommends that all coating systems for immersion shall be inspected for film continuity/defects by visual observation of pin hole rusting through the coating after tank hydro-testing or sea water immersion during sea trials. Alternatively, full immersion of tanks in combination with tanks fully saturated by tank cleaning machine (s), soaking all surfaces with sea water and creating a high condensation environment during sea trials.

All noted defects shall be repaired or reported as outstanding issues.

For onshore storage tanks or for tanks where sea water immersion may not be permitted or practical, coating shall be tested for film continuity/defects as described in ASTM D 5162, method A or B as appropriate for the coating thickness.

The recommended voltage is 400 volts per 100 μ m DFT. The acceptance criterion is no defects. Defects found shall be repaired as per coating specification.

Quality assurance

The following information is the minimum required. The specification may have additional requirements.

- Confirm that all welding and other metal work has been completed before commencing pre-treatment and surface preparation

- Confirm that installed ventilation is balanced and has the capacity to deliver and maintain the RAQ

- Confirm that the required surface preparation standard has been achieved and is held prior to coating application

- Confirm that the climatic conditions are within recommendations in the AG, and are held during the application

- Confirm that the required number of stripe coats have been applied
- Confirm that each coat meets the DFT requirements in the specification
- Confirm that the coating has not been adversely affected by rain or other factors during curing

- Observe that adequate coverage has been achieved on corners, crevices, edges and surfaces where the spray gun cannot be positioned so that its spray impinges on the surface at 90° angle

- Observe that the coating is free from defects, discontinuities, insects, abrasive media and other contamination

- Observe that the coating is free from misses, sags, runs, wrinkles, fat edges, mud cracking, blistering, obvious

pinholes, excessive dry spray, heavy brush marks and excessive film build

- Observe that the uniformity and colour are satisfactory

All noted defects shall be fully repaired to conform to the coating specification.

Caution

This product is for professional use only. The applicators and operators shall be trained, experienced and have the capability and equipment to mix/stir and apply the coatings correctly and according to Jotun's technical documentation. Applicators and operators shall use appropriate personal protection equipment when using this product. This guideline is given based on the current knowledge of the product. Any suggested deviation to suit the site conditions shall be forwarded to the responsible Jotun representative for approval before commencing the work.

For further advice please contact your local Jotun office.

Health and safety

Please observe the precautionary notices displayed on the container. Use under well ventilated conditions. Do not inhale spray mist. Avoid skin contact. Spillage on the skin should immediately be removed with suitable cleanser, soap and water. Eyes should be well flushed with water and medical attention sought immediately.

Accuracy of information

Date of issue: 3 April 2023

Page: 6/7

This Application Guide supersedes those previously issued.



Always refer to and use the current (last issued) version of the TDS, SDS and if available, the AG for this product. Always refer to and use the current (last issued) version of all International and Local Authority Standards referred to in the TDS, AG & SDS for this product.

Colour variation

When applicable, products primarily meant for use as primers or antifoulings may have slight colour variations from batch to batch. Such products and epoxy based products used as a finish coat may chalk when exposed to sunlight and weathering.

Colour and gloss retention on topcoats/finish coats may vary depending on type of colour, exposure environment such as temperature, UV intensity etc., application quality and generic type of paint. Contact your local Jotun office for further information.

Reference to related documents

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

When applicable, refer to the separate application procedure for Jotun products that are approved to classification societies such as PSPC, IMO etc.

Symbols and abbreviations

min = minutes	TDS = Technical Data Sheet
h = hours	AG = Application Guide
d = days	SDS = Safety Data Sheet
°C = degree Celsius	VOC = Volatile Organic Compound
° = unit of angle	MCI = Jotun Multi Colour Industry (tinted colour)
µm = microns = micrometres	RAQ = Required air quantity
g/l = grams per litre	PPE = Personal Protective Equipment
g/kg = grams per kilogram	EU = European Union
m ² /l = square metres per litre	UK = United Kingdom
mg/m ² = milligrams per square metre	EPA = Environmental Protection Agency
psi = unit of pressure, pounds/inch ²	ISO = International Standards Organisation
Bar = unit of pressure	ASTM = American Society of Testing and Materials
RH = Relative humidity (% RH)	AS/NZS = Australian/New Zealand Standards
UV = Ultraviolet	NACE = National Association of Corrosion Engineers
DFT = dry film thickness	SSPC = The Society for Protective Coatings
WFT = wet film thickness	PSPC = Performance Standard for Protective Coatings
	IMO = International Maritime Organization
	ASFP = Association for Specialist Fire Protection

Disclaimer

The information in this document is given to the best of Jotun's knowledge, based on laboratory testing and practical experience. Jotun's products are considered as semi-finished goods and as such, products are often used under conditions beyond Jotun's control. Jotun cannot guarantee anything but the quality of the product itself. Minor product variations may be implemented in order to comply with local requirements. Jotun reserves the right to change the given data without further notice.

Users should always consult Jotun for specific guidance on the general suitability of this product for their needs and specific application practices.

If there is any inconsistency between different language issues of this document, the English (United Kingdom) version will prevail.

Date of issue: 3 April 2023

Page: 7/7

This Application Guide supersedes those previously issued.