

Marathon 1000 XHB

Product description

This is a two component polyamine cured epoxy coating. It is a high build, solvent free, glass flake reinforced product. It has very good impact and abrasion resistance. Suitable for environments with very high corrosivity, such as areas in the splash or tidal zone. Can be used as primer, mid coat, finish coat or as single coat system in atmospheric and immersed environments. Suitable for properly prepared carbon steel, galvanised steel, shop primed steel, concrete and coated surfaces.

Scope

The Application Guide offers product details and recommended practices for the use of the product.

The data and information provided are not definite requirements. They are guidelines to assist with efficient and safe use, and optimum service of the product. Adherence to the guidelines does not relieve the applicator of responsibility for ensuring that the work meets specification requirements. Jotuns liability is in accordance with general product liability rules.

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

Referred standards

Reference is generally made to ISO Standards. When using standards from other regions it is recommended to reference only one corresponding standard for the substrate being treated.

Surface preparation

The required quality of surface preparation can vary depending on the area of use, expected durability and if applicable, project specification.

When preparing new surfaces, maintaining already coated surfaces or aged coatings it is necessary to remove all contamination that can interfere with coating adhesion, and prepare a sound substrate for the subsequent product.

Inspect the surface for hydrocarbon and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area using fresh water.

Paint solvents (thinners) shall not be used for general degreasing or preparation of the surface for painting due to the risk of spreading dissolved hydrocarbon contamination. Paint thinners can be used to treat small localized areas of contamination such as marks from marker pens. Use clean, white cotton cloths that are turned and replaced often. Do not bundle used solvent saturated cloths. Place used cloths into water.

When the surface is an existing coating, verify with technical data sheet and application guide of the involved products, both over coatability and the given maximum over coating interval.

Process sequence

Surface preparation and coating should normally be commenced only after all welding, degreasing, removal of sharp edges, weld spatter and treatment of welds is complete. It is important that all hot work is completed before coating commences.

Soluble salts removal

Soluble salts have a negative impact on the coating systems performance, especially when immersed. Jotun's general recommendations for maximum soluble salts (sampled and measured as per ISO 8502-6 and -9) content on a surface are:

For areas exposed to (ISO 12944-2):

C1-C4: 200 mg/m²

C5M or C5I: 100 mg/m²

Im1-Im3: 80 mg/m²

Carbon steel

Initial rust grade

The steel shall preferably be Rust Grade A or B (ISO 8501-1). It is technically possible to apply the coating to rust grades C and D, but it is practically challenging to ensure specified film thickness on such a rough surface, hence risk of reduced lifetime of the coating system. When steel of Rust Grade C or D is coated, the frequency of inspection and testing should be increased.

Metal finishing

For areas in corrosivity category C1 to C4 (ISO 12944-2) all irregularities, burrs, slivers, slag and spatter on welds, sharp edges and corners shall conform to minimum grade P2 (ISO 8501-3) Table 1, or as specified. For areas in corrosivity category C5, Im1-3 the requirement are for the steel to conform to grade P2 (ISO 8501-3) Table 1. All edges shall have a rounded radius of minimum 2 mm subjected to three pass grinding or equally effective method. One may use a mechanical grinder fitted with a suitable abrasive disc. All sharp irregularities, burrs, slivers, slag and spatter on welds, whether apparent before or after blast cleaning, shall be removed before coating application. It is recommended that welding smoke should be removed by low-pressure Water Cleaning LP WC method (ISO 8501-4) Wa 1 using fresh water. Welding smoke residues are water soluble and could cause blistering if not removed by washing before blasting. Defective welds shall be replaced and treated to an acceptable finish before painting. Temporary welds and brackets shall be ground to a flat finish after removal from the parent metal. Surface preparation and coating should normally be commenced only after all metal finishing and degreasing of a specific area is complete. It is important that as much hot work as possible is completed before coating commences.

Pitting repair

Pittings in steel can be difficult to cover fully with most coatings. In some areas it is practically feasible to use filler to fill pittings. This should then be done either after the initial surface preparation or after application of first coat.

Abrasive blast cleaning

Application of protective coating shall commence before degradation of the surface standard occurs.

Cleanliness

After pre-treatment is complete, the surface shall be dry abrasive blast cleaned to Sa 2½ (ISO 8501-1) using abrasive media suitable to achieve a sharp and angular surface profile.

Surface profile

Recommended surface profile 50-85 µm, grade Medium G (ISO 8503-2). Measure the achieved profile with surface replication tape (Testex) to ISO 8503-5 or by a surface roughness stylus instrument (ISO 8503-4).

Abrasive media quality

The selected abrasive must be compatible with both the surface to be blast cleaned and the specified coating system. The abrasive shall meet specifications as per relevant parts of ISO 11124 (Specification for metallic blast-cleaning abrasives), or ISO 11126 (Specification for non-metallic blast-cleaning abrasives). It should be sampled and tested as per relevant parts of ISO 11125 (metallic abrasives) or ISO 11127 (non-metallic abrasives). Dry storage of abrasive and shelter for blasting pots is necessary to prevent equipment becoming clogged with damp abrasive.

All abrasive blast media used should be new and not recirculated, with the exception of steel grit. If this is utilized the circulation process must include a cleaning process.

Compressed air quality

The supply of clean air to blasting pots must be secured to avoid contamination of abrasive and thereby of blast cleaned surfaces. Compressors must be fitted with sufficient traps for oil and water. It is also recommended to fit two water separators at the blasting machine to ensure a supply of moisture-free air to the abrasive chamber.

Dust contamination

At the completion of abrasive blasting the prepared surface shall be cleaned to remove residues of corrosion products and abrasive media, and inspected for surface particulate contamination. Maximum contamination level is rating 1 (ISO 8502-3) as per Figure 1. Dust size no greater than class 2.

Hand and Power Tool Cleaning

Power tool cleaning

Minor damage of the coating may be prepared to St 2 (ISO 8501-1). Suitable method is disc grinding with rough discs only. Ensure the surface is free from mill scale, residual corrosion, failed coating and is suitable for painting. The surface should appear rough and mat.

Overlapping zones to intact coating shall have all leading edges feathered back by sanding methods to remove all sharp leading edges and establish a smooth transition from the exposed substrate to the surrounding coating. Consecutive layers of coating shall be feathered to expose each layer and new coating shall always overlap to an abraded existing layer. Abrade intact coatings around the damaged areas for a minimum 100 mm to ensure a mat, rough surface profile, suitable for over coating.

Galvanised steel

Abrasive blast cleaning

The galvanised finish shall be smooth as is consistent for a protective coating and shall have no sharp fins, sharp edges, dross or zinc ash on the surface. If present, remove by mechanical cleaning methods.

After removal of excess zinc and surface defects the area to be coated shall be degreased to ISO 12944-4, Part 6.2.4 Alkaline Cleaning. The galvanised surface shall be sweep blast-cleaned with the nozzle angle at 45-60° from perpendicular at reduced nozzle pressure to create a sharp and angular surface profile using approved non-metallic abrasive media. As a guide, a surface profile 25-55 µm, grade Fine G; Ry5 (ISO 8503-2) should be achieved.

Hand and Power Tool Cleaning

After removal of excess zinc and surface defects the area to be coated shall be degreased with an alkaline detergent, washed by Low-Pressure Water Cleaning (LPWC) to a grade corresponding to the description of Wa 1 (ISO 8501-4) or higher standard and the surface abraded using mechanical or hand sanding methods using non-metallic abrasives or bonded fibre abrasive pads to remove all polish and to impart a scratch pattern to the surface. Do not use high speed rotational sanders.

Concrete

Blast cleaning

Dry abrasive blast cleaning to SSPC-SP 13/NACE No. 6. Where the concrete has become contaminated with oils, grease, or fuels, alkaline detergent may be used to remove the contaminants. It is important to only clean an area that can be fully washed down after degreasing before the cleaner can dry on the surface. Where the contamination has penetrated deep in to the substrate it may be necessary to use Flame/ Thermal cleaning. All prepared surfaces should then have all "blow holes" and other surface defects filled with suitable filler that is compatible with the primer and finish coat system to ensure that the coating can be applied over a smooth and regular substrate.

Diamond disc grinding

Diamond grind the surface to remove all laitance and expose the aggregates.

Coated surfaces

Verification of existing coatings including primers

When the surface is an existing coating, verify with technical data sheet and application guide of the involved products, both over coatability and the given maximum over coating interval.

Over coating

High pressure water jetting surface preparation refers to ISO 8501-4, for substrates previously coated either with a full coating system (surface DC A, DC B, DC C) or shop primer (surface DP I and DP Z). The surface definition for existing coating (DC) refers to the degree of coating breakdown according to ISO 4628. It is important before considering water jetting, to ensure that the specified coating system is compatible with the existing coating system. High pressure water jetting does not remove mill scale or create surface roughness, and is only useful for surfaces with an initial roughness suitable for the subsequent coat.

Shop primers

Surfaces not contaminated with hydrocarbon deposits shall be cleaned by Low-pressure Water Cleaning (LPWC) to a grade corresponding to the description of Wa 1 (ISO 8501-4) or higher standard using fresh water to remove all dusts, chloride and non-visible contamination.

Optimum performance is achieved with preparation to a grade corresponding to the description of Wa 2½.

Minimum preparation grade is Wa 1.

Maximum accepted flash rust grade is Moderate (M).

Application

Acceptable environmental conditions - before and during application

Before application, test the atmospheric conditions in the vicinity of the substrate for the dew formation according to ISO 8502-4.

| | | |
|------------------------|---------|----|
| Air temperature | 5 - 60 | °C |
| Substrate temperature | 5 - 50 | °C |
| Relative Humidity (RH) | 10 - 85 | % |

The following restrictions must be observed:

- Only apply the coating when the substrate temperature is at least 3 °C (5 °F) above the dew point
- Do not apply the coating if the substrate is wet or likely to become wet
- Do not apply the coating if the weather is clearly deteriorating or unfavourable for application or curing
- Do not apply the coating in high wind conditions

Heating is needed for application below 15 °C.

Paint temperature to be minimum 20 °C before application with atmosphere temperature below 15 °C. When temperature is below 15 °C insulated hoses are recommended.

Product mixing

Product mixing ratio (by volume)

| | |
|--------------------------|-----------|
| Marathon 1000 XHB Comp A | 3 part(s) |
| Marathon 1000 XHB Comp B | 1 part(s) |

Induction time and Pot life

Paint temperature **23 °C**

Pot life 45 min

The temperature of base and curing agent is recommended to be 20 °C or higher when the product is mixed.

Thinner/Cleaning solvent

Thinner: Jotun Thinner No. 17

Thinning max.: 3 %

Thinning is not normally required. Consult the local representative for advice during application in extreme conditions. Do not thin more than allowed by local environmental legislation.

Note: Korean VOC regulation "Korea Clean Air Conservation Act" and its corresponding thinning limit will prevail over recommended thinning volumes.

Thinning reduces viscosity but also decrease sag resistance.

Thinning must be done with care as this will result in lower maximum film thickness. Excessive thinning can also lead to solvent entrapment, particularly in hot weather, reducing in coating hardness, decrease in abrasion resistance.

Application data

Spray application

Airless Spray Equipment

| | |
|---------------------------------|--|
| Pump ratio (minimum) : | 68:1 |
| Pressure at nozzle (minimum) : | 150 bar/2100 psi |
| Nozzle tip (inch/1000) : | 21-27 |
| Nozzle output (litres/minute) : | 1.9 - 3.2 |
| Filters (mesh) : | Remove filters |
| Material hose length : | Max 45 m (Longer hoselengths require higher pump capacity / pressure ratio.) |

Several factors influence, and need to be observed to maintain the recommended pressure at the nozzle. Among factors causing pressure drop are:

- extended hoses or hose bundles
- extended hose whip-end line
- small internal diameter hoses
- high paint viscosity
- large spray nozzle size
- inadequate air capacity from compressor
- incorrect or clogged filters

Plural component (Twin Pump) airless spray equipment

When using plural spray equipment, Jotun recommends the use of either a pump with computerised pump ratio settings or fixed ratio settings in combination with a flow meter for each pump to monitor the proper delivery ratio of the coating components is maintained during use.

Recommended data for pump output, pressure at nozzle, nozzle tip and filters are the same as for airless spray equipment. It is recommended to store both components at 20-25 °C before use.

Heating of the components and heating in the paint lines is recommended at low temperature. The temperature shall be adjusted so that the temperature of the paint in the gun during application is 30 °C - 40 °C.

Film thickness per coat

Typical recommended specification range

| | |
|----------------------------|-------------------------------|
| Dry film thickness | 400 - 1000 μm |
| Wet film thickness | 410 - 1020 μm |
| Theoretical spreading rate | 2.4 - 1 m^2/l |

Film thickness measurement

Wet film thickness (WFT) measurement and calculation

To ensure correct film thickness, it is recommended to measure the wet film thickness continuously during application using a painter's wet film comb (ISO 2808 Method 1A). The measurements should be done as soon as possible after application.

Fast drying paints may give incorrect (too low) readings resulting in excessive dry film thickness. For multi layer physically drying (resoluble) coating systems the wet film thickness comb may give too high readings resulting in too low dry film thickness of the intermediate and top coats.

Use a wet-to-dry film calculation table (available on the Jotun Web site) to calculate the required wet film thickness per coat.

Dry film thickness (DFT) measurement

When the coating has cured to hard dry state the dry film thickness can be checked to SSPC PA 2 or equivalent standard using statistical sampling to verify the actual dry film thickness. Measurement and control of the WFT and DFT on welds is done by measuring adjacent to and no further than 15 mm from the weld.

Ventilation

Sufficient ventilation is very important to ensure proper drying/curing of the film.

Stripe coating

The stripe coat sequence can be either of the following:

1. Surface preparation, stripe coat, full coat.
2. Surface preparation, full coat, stripe coat. This sequence can be used when a large substrate area has been prepared and leaving the substrate exposed for a long time while doing stripe coating could lead to surface deterioration.

It is important to pay special attention to edges, openings, rear sides of stiffeners, scallops etc. and to apply a stripe coat to these areas where the spray fan may not reach or deposit an even film.

When applying a stripe coat to bare metal use only a stiff, round stripe coating brush to ensure surface wetting and filling of pits in the surface.

Stripe coating shall be of a different colour to the main primer coat and the topcoat colour and should be applied in an even film thickness, avoiding excessive brush marks in order to avoid entrapped air. Care should be taken to avoid excessive film thickness. Pay additional attention to pot life during application of stripe coats.

Jotun recommends a minimum of one stripe coat. However, in extremely aggressive exposure conditions there may be good reason to specify two stripe coats.

Drying process

Do not attempt to speed up the curing process by blowing hot air on to the wet coating film as this may lead to skin drying/curing, entrapped solvents and consequently solvent blistering and inferior corrosion protection.

Coating loss

The consumption of paint should be controlled carefully, with thorough planning and a practical approach to reducing loss. Application of liquid coatings will result in some material loss. Understanding the ways that coating can be lost during the application process, and making appropriate changes, can help reducing material loss.

Some of the factors that can influence the loss of coating material are:

- type of spray gun/unit used
- air pressure used for airless pump or for atomization
- orifice size of the spray tip or nozzle
- fan width of the spray tip or nozzle
- the amount of thinner added
- the distance between spray gun and substrate
- the profile or surface roughness of the substrate. Higher profiles will lead to a higher "dead volume"
- the shape of the substrate target
- environmental conditions such as wind and air temperature

Drying and Curing time

| Substrate temperature | 5 °C | 10 °C | 15 °C | 23 °C | 40 °C |
|---------------------------|------|-------|-------|-------|-------|
| Surface (touch) dry | 22 h | 14 h | 10 h | 7 h | 4 h |
| Walk-on-dry | 33 h | 19 h | 16 h | 9 h | 6 h |
| Dry to over coat, minimum | 33 h | 19 h | 16 h | 9 h | 6 h |
| Dried/cured for immersion | 14 d | 10 d | 10 d | 7 d | 3 d |
| Dried/cured for service | 14 d | 10 d | 10 d | 7 d | 3 d |

Drying and curing times are determined under controlled temperatures and relative humidity below 85 %, and at average of the DFT range for the product.

Surface (touch) dry: The state of drying when slight pressure with a finger does not leave an imprint or reveal tackiness.

Walk-on-dry: Minimum time before the coating can tolerate normal foot traffic without permanent marks, imprints or other physical damage.

Dry to over coat, minimum: The recommended shortest time before the next coat can be applied.

Dried/cured for immersion: Minimum time before the coating can be permanently immersed in sea water.

Dried/cured for service: Minimum time before the coating can be permanently exposed to the intended environment/medium.

Maximum over coating intervals

Maximum time before thorough surface preparation is required. The surface must be clean and dry and suitable for over coating. Inspect the surface for chalking and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area by low-pressure water cleaning using fresh water.

If maximum over coating interval is exceeded the surface should in addition be carefully roughened to ensure good inter coat adhesion.

Areas for atmospheric exposure

| Average temperature during drying/curing | 5 °C | 10 °C | 15 °C | 23 °C | 40 °C |
|--|------|-------|-------|-------|-------|
| Itself | 10 d | 7 d | 5 d | 3 d | 2 d |

| | | | | | |
|--------------|------|-----|-----|-----|-----|
| epoxy | 10 d | 7 d | 5 d | 3 d | 2 d |
| polyurethane | 10 d | 7 d | 5 d | 3 d | 2 d |
| vinyl epoxy | 10 d | 7 d | 5 d | 3 d | 2 d |
| polysiloxane | 10 d | 7 d | 5 d | 3 d | 2 d |

Areas for immersed exposure

| Average temperature during drying/curing | 5 °C | 10 °C | 15 °C | 23 °C | 40 °C |
|--|------|-------|-------|-------|-------|
| Itself | 10 d | 7 d | 5 d | 3 d | 2 d |
| epoxy | 10 d | 7 d | 5 d | 3 d | 2 d |
| vinyl epoxy | 10 d | 7 d | 5 d | 3 d | 2 d |

Other conditions that can affect drying / curing / over coating

Adding anti-skid to the coating system

Anti skid aggregate should only be added in the final coat, and should not be used in single coat systems. Spread the aggregate evenly on the surface before half of time to Surface dry. Use Jotun Anti-skid, medium particle size (400 - 600 µm) for coatings applied in 150 to 400 µm DFT. The recommended usage is 2.5 - 3.3 kg per 10 litres of paint.

Repair of coating system

Damages to the coating layers:

Prepare the area through sandpapering or grinding, followed by thorough cleaning/vacuuming. When the surface is clean and dry the coating may be over coated by itself or by another product, ref. original specification.

Always observe the maximum over coating intervals. If the maximum over coating interval is exceeded the surface should be carefully roughened in order to ensure good intercoat adhesion.

Damages exposing bare substrate:

Remove all rust, loose paint, grease or other contaminants by spot blasting, mechanical grinding, water and/or solvent washing. Feather edges and roughen the overlap zone of surrounding intact coating. Apply the coating system specified for repair.

Repair of damaged areas

Sags and runs can be caused by too high wet film thickness, too much thinner added or the spray gun used too close to the surface.

Repair by using a paint brush to smooth the film when still wet.

Sand down to a rough, even surface and re-coat if the coating is cured.

Orange peel can be caused by poor flow/levelling properties of the paint, poor atomization of the paint, thinner evaporating too fast or the spray gun held too close to the surface.

This can be rectified by abrading the surface and applying an additional coat after having adjusted the application properties or the application technique.

Dry spray can be caused by poor atomization of the paint, spray gun held too far from the surface, high air temperature, thinner evaporating too fast or coating applied in windy conditions.

Sand down to a rough even surface and re-coat.

Pinholes can be caused by entrapped solvents in the film or by incorrect application technique. Pinholes can be repaired as per procedure for damages to the coating layer or to the substrate, ref. above.

Coating film continuity

When required by the specification, the coating shall be tested for film discontinuity according to ASTM D 5162, test method A or B as appropriate for the actual dry film thickness.

All recorded defects shall be repaired by best practical means.

Quality assurance

The following information is the minimum required. The specification may have additional requirements.

- Confirm that all welding and other metal work has been completed before commencing pre-treatment and surface preparation
- Confirm that installed ventilation is balanced and has the capacity to deliver and maintain the RAQ
- Confirm that the required surface preparation standard has been achieved and is held prior to coating application
- Confirm that the climatic conditions are within recommendations in the AG, and are held during the application
- Confirm that the required number of stripe coats have been applied
- Confirm that each coat meets the DFT requirements in the specification
- Confirm that the coating has not been adversely affected by rain or other factors during curing
- Observe that adequate coverage has been achieved on corners, crevices, edges and surfaces where the spray gun cannot be positioned so that its spray impinges on the surface at 90° angle
- Observe that the coating is free from defects, discontinuities, insects, abrasive media and other contamination
- Observe that the coating is free from misses, sags, runs, wrinkles, fat edges, mud cracking, blistering, obvious pinholes, excessive dry spray, heavy brush marks and excessive film build
- Observe that the uniformity and colour are satisfactory

All noted defects shall be fully repaired to conform to the coating specification.

Caution

This product is for professional use only. The applicators and operators shall be trained, experienced and have the capability and equipment to mix/stir and apply the coatings correctly and according to Jotun's technical documentation. Applicators and operators shall use appropriate personal protection equipment when using this product. This guideline is given based on the current knowledge of the product. Any suggested deviation to suit the site conditions shall be forwarded to the responsible Jotun representative for approval before commencing the work.

For further advice please contact your local Jotun office.

Health and safety

Please observe the precautionary notices displayed on the container. Use under well ventilated conditions. Do not inhale spray mist. Avoid skin contact. Spillage on the skin should immediately be removed with suitable cleanser, soap and water. Eyes should be well flushed with water and medical attention sought immediately.

Accuracy of information

Always refer to and use the current (last issued) version of the TDS, SDS and if available, the AG for this product. Always refer to and use the current (last issued) version of all International and Local Authority Standards referred to in the TDS, AG & SDS for this product.

Colour variation

When applicable, products primarily meant for use as primers or antifoulings may have slight colour variations from batch to batch. Such products and epoxy based products used as a finish coat may chalk when exposed to sunlight and weathering.

Colour and gloss retention on topcoats/finish coats may vary depending on type of colour, exposure environment such as temperature, UV intensity etc., application quality and generic type of paint. Contact your local Jotun office for further information.

Reference to related documents

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

When applicable, refer to the separate application procedure for Jotun products that are approved to classification societies such as PSPC, IMO etc.

Symbols and abbreviations

min = minutes
h = hours
d = days
°C = degree Celsius
° = unit of angle

TDS = Technical Data Sheet
AG = Application Guide
SDS = Safety Data Sheet
VOC = Volatile Organic Compound
MCI = Jotun Multi Colour Industry (tinted colour)

μm = microns = micrometres
g/l = grams per litre
g/kg = grams per kilogram
 m^2/l = square metres per litre
 mg/m^2 = milligrams per square metre
psi = unit of pressure, pounds/inch²
Bar = unit of pressure
RH = Relative humidity (% RH)
UV = Ultraviolet
DFT = dry film thickness
WFT = wet film thickness

RAQ = Required air quantity
PPE = Personal Protective Equipment
EU = European Union
UK = United Kingdom
EPA = Environmental Protection Agency
ISO = International Standards Organisation
ASTM = American Society of Testing and Materials
AS/NZS = Australian/New Zealand Standards
NACE = National Association of Corrosion Engineers
SSPC = The Society for Protective Coatings
PSPC = Performance Standard for Protective Coatings
IMO = International Maritime Organization
ASFP = Association for Specialist Fire Protection

Disclaimer

The information in this document is given to the best of Jotun's knowledge, based on laboratory testing and practical experience. Jotun's products are considered as semi-finished goods and as such, products are often used under conditions beyond Jotun's control. Jotun cannot guarantee anything but the quality of the product itself. Minor product variations may be implemented in order to comply with local requirements. Jotun reserves the right to change the given data without further notice.

Users should always consult Jotun for specific guidance on the general suitability of this product for their needs and specific application practices.

If there is any inconsistency between different language issues of this document, the English (United Kingdom) version will prevail.